

The Grandview entry system

The Directory:


The arrow keys (the upper right and left buttons) allow visitors to scroll through the resident directory either from the beginning or end of the alphabet. This will provide the visitor with the resident's 3-digit directory code needed to contact the resident for access.

Visitor Access:

Push this button (far left) & then dial the resident's 3-digit directory code. The resident will push the #6 on their telephone to grant the caller access.

General Information:

- The resident's phone number is never displayed to the visitor.
- If the phone line is busy, the system relays that information to the visitor.
- Pressing either the Resident or Visitor Access key will clear any misdialed numbers.



Information:

The "i" button (top row, center) provides both text and audio instructions for visitors on how to use the system in both English and Spanish.

Full color camera:

You can view who is calling you on channel 61 of your television.

- Your key will unlock all common areas however the front and back door are controlled by the FOB portion of the key. All you need to do is wave the key by the electronic reader to open the entry doors. If you loose your key, contact Reba immediately so it can be disabled and replaced.

- There is a second key pad to the left of the exterior door. This will allow access into the vestibule only. The current code is 4022#. You may give this code to friends or vendors to provide them access to the entry system between the hours of 10 PM and 6 AM when the exterior doors are locked. **No one can enter the building with this code.**

As always, feel free to contact Reba if you have any questions or concerns at (206) 250-0322 or reba@grandviewseattle.com.

Building Specific Information